


Current/Correct ONX-F11-03 LH Rev B- Forward Upper Longeron
 Make from 1" x 1" x 0.125" 6061-T6 Aluminum Angle



Archived ONX-F11-03 LH Rev A- Forward Upper Longeron
 Make from 1" x 1" x 0.125" 6061-T6 Aluminum Angle